



# INSTALLATION INSTRUCTIONS for HS-12 16" WIDE HAND SINK with ELECTRONIC FAUCET, OVERFLOW & P-TRAP

## INCLUDES:

- (A) HAND SINK
- (B) ELECTRONIC FAUCET
- (C) WALL MOUNT BRACKET
- (D) OVERFLOW & P-TRAP

1. Install ELECTRONIC FAUCET (B) on HAND SINK (A) as shown in diagram and hook up water inlet leads (not provided)
2. Hang HAND SINK (A) on WALL BRACKET (C).
3. Install Drain with plumbers putty on top and the rubber washer & locknut below. Make sure top of drain is below surface to allow proper drainage.
4. Hook up water and drain line with OVERFLOW & P-TRAP (D). Connect hose from OVERFLOW HOLE (D) to back of P-TRAP (D)

