



INSTALLATION INSTRUCTIONS for HS-22 16" WIDE WALL MOUNT HAND SINK with HEAVY-DUTY FAUCET

INCLUDES:

- (A) HAND SINK
- (B) HEAVY-DUTY FAUCET
- (C) WALL MOUNT BRACKET

1. Install HEAVY-DUTY FAUCET (B) on HAND SINK (A) and hook up water inlet leads (not provided)
2. Hang HAND SINK (A) on WALL BRACKET (C).
3. Install Drain with plumbers putty on top and the rubber washer & locknut below. Make sure top of drain is below surface to allow proper drainage.
4. Hook up water and drain lines to complete the installation.

