



# INSTALLATION INSTRUCTIONS for HS-4 16" WIDE WALL MOUNT HAND SINK with OVERFLOW & P-TRAP

## INCLUDES:

- (A) HAND SINK with SIDE SPLASHES
- (B) BACKSPLASH WALL MOUNT FAUCET
- (C) WALL MOUNT BRACKET
- (D) OVERFLOW & P-TRAP

1. Install FAUCET (B) on HAND SINK with SIDE SPLASHES (A) and hook up water inlet leads (not provided)
2. Hang HAND SINK with SIDE SPLASHES (A) on WALL BRACKET (C).
3. Install Drain with plumbers putty on top and the rubber washer & locknut below. Make sure top of drain is below surface to allow proper drainage.
4. Hook up water and drain line with OVERFLOW & P-TRAP (D). Connect hose from OVERFLOW HOLE (D) to back of P-TRAP (D)

