



# INSTALLATION INSTRUCTIONS for HS-5 16" WIDE WALL MOUNT HAND SINK with SIDE SPLASHES & P-TRAP

## INCLUDES:

- (A) HAND SINK with SIDE SPLASHES
- (B) BACKSPASH WALL MOUNT FAUCET
- (C) WALL MOUNT BRACKET
- (D) P-TRAP

1. Install FAUCET (B) on HAND SINK with SIDE SPLASHES (A) and hook up water inlet leads (not provided)
2. Hang HAND SINK with SIDE SPLASHES (A) on WALL BRACKET (C).
3. Install Drain with plumbers putty on top and the rubber washer & locknut below. Make sure top of drain is below surface to allow proper drainage.
4. Hook up water and drain line with P-TRAP (D).

