



INSTALLATION INSTRUCTIONS for HS-6 16" WIDE WALL MOUNT HAND SINK with 4" CENTER FAUCET HOLES

INCLUDES:

- (A) HAND SINK
- (B) WALL MOUNT BRACKET

***NOTE: THIS HAND SINK DOES NOT INCLUDE A FAUCET. 4" CENTER HOLES ARE PRE-DRILLED**

1. Hang HAND SINK (A) on WALL BRACKET (C).
2. Install Drain with plumbers putty on top and the rubber washer & locknut below. Make sure top of drain is below surface to allow proper drainage.
3. Hook up water and drain lines to complete the installation.

