



INSTALLATION INSTRUCTIONS for HS-7 SOAP & TOWEL HAND SINK

INCLUDES:

- (A) HAND SINK
- (B) BACKSPLASH WALL MOUNT FAUCET
- (C) WALL MOUNT BRACKET
- (D) TOWEL & SOAP DISPENSER
- (E) WALL MOUNT SOAP DISPENSER

1. Install FAUCET (B) on HAND SINK (A) and hook up water inlet leads (not provided)
2. Install TOWEL & SOAP DISPENSER (D) on wall with the top of the unit 55" off the finished floor and making sure it is level. Open the towel dispenser door and mark the 3 key slots on the top as well as the 2 bottom holes. Using appropriate mounting hardware (not included) install 3 screws at the top of the key slots and install only the mounting hardware for the bottom 2 holes (screws will be installed later). Hang HAND SINK (A) on wall and install WALL BRACKET (C) with opening facing up by inserting screws through TOWEL DISPENSER (D) and into mounting hardware that was previously installed.
3. Install SOAP DISPENSER (E) on front of TOWEL & SOAP DISPENSER (D).
4. Hang HAND SINK (A) on WALL BRACKET (C).
5. Install Drain with plumbers putty on top and the rubber washer & locknut below. Make sure top of drain is below surface to allow proper drainage.
6. Hook up water and drain lines to complete the installation.

