



6"-7" Adjustable Height Plate Caster

Installation Instructions

1. Loosen two allen screws on side of caster stem to allow for adjustment.
2. Hold base of caster stem & turn stem until raised to the desired height.
3. Tighten allen screws so wheel & swivel will be locked in place.



Contact Us

NOTE: Locking front brake will prevent lower section of caster from rotating as well as secure wheel in place