



# AC ADAPTER INSTALLATION INSTRUCTIONS for ELECTRONIC HAND SINKS

## PARTS:

- (A) CONTROL BOX
- (B) PCB BOARD
- (C) AC TRANSFORMER
- (C1) AC TRANSFORMER LEAD
- (D) BATTERY PACK LEAD
- (E) LEAD SLOT
- (F) AC/DC SWITCH

## SWITCHING FROM BATTERY TO AC ADAPTER:

1. Open the Control Box (A).
2. Disconnect the Battery Pack Lead (D) from the PCB Board (B) inside the Control Box (A).
3. Plug the AC Transformer Lead (C1) into the same Lead Slot (E) that the Battery Pack Lead (D) came from.
4. Flip the AC/DC switch (F)
5. Run cable out of Control Box (A) and install rubber grommet to seal the hole.
6. Plug the AC Transformer (C) to electrical outlet.

